

CABINET PARTS



CABINET PARTS

Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION
1		Literature Parts Use & Care Guide Energy Tag Tech Sheet	13 14 15	8208155 4344198 8170980 8170981	Hinge, Center Black	30 32 33 37 38	8170925 8171247 8170861	Cover, Unit Power Cord Insulation, Sound Tube, Drain Clip, Drain Tube
2		Cabinet (Not a Servicable Part)	16 17	4343675		41 42		Hinge, Top Cover, Hinge
3 4 5 6 7 8	8170869 4344177	Plug, Button (3) White Black Biscuit	19 20 22	8170860 8170858 8170859 8171067 8171066 8171202	White Black Biscuit Hinge, Bottom White Black Screw Grille Assembly	43 44 46	8208236	White Black
9 10 11 12	8171215 8171004 8171002 8171003 4344186 8170373	(Front Roller) Screw Hinge Cover, Bottom White Black Biscuit Screw	25 27	8170866 8170867 8170868 4344167 8170920	Black Biscuit	Follo		rts Not Illustrated Clamp, Tube

FREEZER LINER PARTS



FREEZER LINER PARTS


For Models: GB2SHDXPQ01, GB2SHDXPB01, GB2SHDXPT01, GB2SHDXPS01 (White) (Black) (Biscuit) (Stainless Steel)

Illus. No.	Part No.	DESCRIPTION
1		Liner (Not A
		Seviceable Part)
2	8170897	Gasket, Foam
3 4	8171237 8208205	Gear Cover, Light
5	8171229	Shaft
6	8170839	Socket, Light
7	8171236	Gear
8	8170456	Screw
9 10	8208190 8170838	Bulb, Light Housing, Frz. Light
11	8208235	Cover, Evaporator
12	4344167	Screw
13		Bracket, Door
	8171232	Left
14	8171233 8208206	Right Housing, Lighting
15	8171238	
16	8170842	Switch, Light
18	0.474004	Bracket, Basket
	8171234 8171235	Left Right
19	8208214	•
20	8208203	Gasket, Bottom
21		Bracket, Slide
	8208215	Left
22	8208216 8170881	Right Cover, Fan Shroud
23	8171153	Shroud, Evap.Fan
24	8170544	Blade, Fan
		(Evaporator)
25	8171086 8170894	Grommet (2)
26 27	4344385	Motor, Evaporator Funnel, Drain
21	1011000	(Incl. # 28 & 29)
28	4344311	Seal
29	4344310	Gasket
30 31	8208196 8208202	Thermistor Cover, Thermistor
31 32	8208202	Screw
33	4343670	Screw
33	4343670	Screw

Following Parts Not Illustrated


8208199 Harness, Lights (Freezer)

FREEZER DOOR PARTS



Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION
2	8170776 8170961	Black Biscuit Stainless Steel Handle White Black	3	8171163 8171162 8170752 8170785 8170786	Black Trim, Handle White Black	5 6 7	8170499 8208212 8208213 8170953 4343926	Plug, Button (2) White Black Plug, Button (1) White


REFRIGERATOR LINER PARTS



Illus. No.	Part No.	DESCRIPTION	Illus.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION
1		Liner (Not A Serviceable Part)	9		Bulb, Light (2) Socket, Light (2)	Follo	owing P	arts Not Illustrated
2	8208184	Bracket, Control and Lights	11	8208191			820819	7 Harness,
3	8208185		12	8208192			000040	Damper Control
4	8208186	Housing, Electronic Control	13 14		Cover, Damper Insulation		820819	8 Harness, Controls (Refrigerator)
5	8208187	Electronic Control	15		Control, Damper			(Includes # 16)
6	4344571	Switch, Light	16		Thermistor			
7	8208188	Cover, Light						
8	8208189	Housing, Light						

REFRIGERATOR DOOR PARTS

For Models: GB2SHDXPQ01, GB2SHDXPB01, GB2SHDXPT01, GB2SHDXPS01 (White) (Black) (Biscuit) (Stainless Steel)




FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

REFRIGERATOR DOOR PARTS

IIIus. No.	Part No.	DESCRIPTION
1		Refrigerator Door
		(w/ Insulation)
	8171171	White
	8208225	
	8171203	Biscuit
2	8208224 8171204	Stainless Steel Door, Compartment
3 4 5	8170793	
5	8171166	Shelf Bin
Ū	0	(Medium)
6		Plug, Handle Hole
	4344535	White
	4344533	Black
-	8170495	Biscuit
7	8208212	Plug, Button White
	8208212	Black
8	0200213	Door Gasket,
Ū		Magnetic
	8171197	White
	8170758	Black
9		Door Handle
	8170776	White
	8170961 8170777	Black Biscuit
11	01/0///	Door Closure
	8171245	White
	8171246	Black
13		Trim, Handle
	8170752	White
	8170785	
	8170786	Biscuit
14 15	8170795 4344333	Shelf, Bin (Large)
17	4344333	Screw Stop, Door
17	8171205	White
	8171214	
	8171206	Biscuit
21	8170499	Screw
23		Bushing
	8208208	
24	8171213	Black
24	8170953	Plug, Button White
	4343926	Black
25	8170797	Nameplate
	2	

UNIT PARTS




FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

UNIT PARTS

Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION
1 2 3 4 7 8 9 10 11 12 13 14 15 17 18 20 22	4343865 8208223 8208232 4344167 8208204 8170911 8171209 8171152 8170724 8171210 8170914 8170904 8170912 8170462 8171211 8170882	Screw Blade, Fan Base Screw Harness, Evap. Heater Drain Pan Grommet (3) Evaporator Heater Strap Overload (Includes Relay)	23 24 25 26 27 28 31 32 34 36 39 40 41 42 43 44 53 55	8171155 8171154 8208221 4343918 8208233 4344268 8171208 8170906 8208222 8170901 8170916 4343845 8208234 8170917 4344219 8170902 8171253 4344292	Dam Right Side Left Side Motor, Fan Clip, Heater Harness, Unit Drier Compressor (Includes Items 11, 12, 15, 17 & 27) Shroud Bracket, Fan Motor Clip, Drier Roller Grommet (4) Screw Axle, Roller Clip, Evaporator Screw Screw	Follo and O	wing Pa ptional 978025 978026 978027 978028 978029 978030 876764	Valve, Access (1/4") Valve, Access (5/16") Valve, Access (3/8") Valve, Access (1/2") Valve, Access (1/2") Valve, Access (5/8") Valve, Access (3/4") Valve, Access (3/4") Valve, Access (3/16") NT CHARGE 5.00 Ozs.
			I			1		(R-134A)


SHELF PARTS



SHELF PARTS

Illus. No.	Part No.	DESCRIPTION
1	4344167	Screw
2	4344294	
3	8171227	Divider, Basket
		(Lower)
4	8208181	Basket, Freezer
		(Upper)
5	8171225	,
		(Lower)
6 7	8208220	,
7	4344381	Frame, Shelf
_		(Meat Pan)
9	8170754	
10	8171226	Divider, Basket
4.4	0470700	(Upper)
11	8170763	
12	8170964	, ,
13	0000000	Support, Crisper
	8208230 8208231	Left Side
16	8171073	Right Side Screw
17	8170717	Crisper (2)
18	8170554	Support, Crisper Cvr
20	8171168	Frame, Crisper
21	8170560	Glass, Crisper Cover
22	8170870	Ladder, Center
23	8170871	Ladder, Side
26		
24 25 26	4344396 8170578 8170709	Screw Screw Bin, Egg

ICEMAKER PARTS



ICEMAKER PARTS

Illus. No.	Part No.	DESCRIPTION					
1		Mold & Heater (Not Available, Order 4396418)					
2 3 4 5 6 7	4344265 8170928 8170927 8170929 8170932 8170930	Assembly Clip Bearing & Inlet Ejector Ice Stripper Support Retainer, Thermostat (2) Thermostat (Not Available,					
9 10 11 12 14 15 16 18	8170933 8170414 8170926 4343702 8171289 8170938 8170931 8208238	Pan, Ice Clip Shutoff Arm Harness, Ice Maker Clip, Ice Maker Cover Module Assembly (Not Available,					
20 24 25 26 27 28 29 30	8208237 8170943 4343704 4344402 8170934 4343686 4343984 4343675	Order 4396418) Valve, Water Inlet Screw Compression Nut Insert, Tube Tube, Water Spring Clip, Wire Screw					
	Note: The Following Parts Are Components Of Accessory Bag						
	4344548 488878 4344549 4344316	Coupling Tube Clamp Plug, Hole Plug, Button					

OPTIONAL PARTS

For Models: GB2SHDXPQ01, GB2SHDXPB01, GB2SHDXPT01, GB2SHDXPS01 (White) (Black) (Biscuit) (Stainless Steel)

DESCRIPTION

Illus. **Part** No.

No. **DESCRIPTION**

Part

No.

Illus.

No.

Illus. **Part** No. No. **DESCRIPTION**

PAINT, TOUCH-UP (1/2oz.)

72017 White 72032 Black 4392901 Biscuit

PAINT, PRESSURIZED SPRAY (12 oz.)

> *350942 Primer, White *350930 White *350939 Black *4392901 Biscuit

*Important: The spray paint is not to be used where the paint may make contact with the door gaskets.

PAINT, BULK (1 qt.)

799344 White (Uncut) 799344 Black (Uncut) 4392900 Biscuit (Uncut)

Miscellaneous

212643 Sealer, Gum (4 Feet) 479502 Tape, Vinyl (3/4 x 108") 505587 Sealer, Mastic (1 Qt.) 503695 Cork, Sealer (1/4 Pound) 542638 Grease, Silicone (1/2 Oz.) 542639 Cement, Alumilastic (1-1/4 Oz.) 799833 Kit, Evaporator Repair (Aluminum Epoxy) 833938 Kit, Terminal Connector

TORX SCREW WRENCH

1117510 Torx Key

ACCESSORIES

2217192 Cleaner, Stainless Steel